

**!!!!!! IMPORTANT NOTICE REGARDING YOUR PHONE !!!!!!**

If you are replacing a defective phone, please **TURN OFF** set relocation: prior to replacing the defective phone. Failure to do so will result in **loss of programming** and the present assigned **extension number will also be lost!**

Press **FEATURE \*\* 266344** & Enter Password: **266344**

**If your Display Reads: "A. Configuration" Follow The Instructions Below:**

Press: **SHOW**

Display will read: "**Trk/Line Data**"

Press: **NEXT**

Display will read: "**Line Access**"

Press: **NEXT** until the Display reads: "**Miscellaneous**"

Press: **SHOW**

Display will read: "**Backgrnd music**"

Press: **NEXT** until the Display reads: "**Set relocation: Y or N**"

Press the **CHANGE** softkey until it displays **Y** for ON / **N** for OFF

Press the **RLS** key.

Press **FEATURE \*\* 266344** & Enter Password: **266344**

**If your Display Reads: "Terminals & Sets" Follow The Instructions Below:**

Press: **NEXT** until the display reads: "**System Programming**"

Press: **SHOW**

Display will read: "**Hunt Groups**" or "**Change DNs**"

Press: **NEXT** until the display reads: "**Featr settings**"

Press: **SHOW**

Display will read: "**Backgrnd music**"

Press: **NEXT** until the display reads: "**Set relocation**"

Press the **CHANGE** softkey to toggle the setting to Yes or No

Press the **RLS** key.



M7310



M7324

**Programming Template**



Place template over buttons according to your phone model

**WARNING: Wait 15 min. before moving phones after making a change to Set Relocation**